



WARRANTY

15W Non Dimmable **LED Driver** with PWM Output

Features of the: **BNV-15 Series**



Constant Voltage Output



For Indoor



AC Input Range: 180-264VAC



Cooling by Free Air Convection



Protections:

- Short Circuit
- Over Load
- Over Voltage
- Over Termperature



Factory Fitted Flex and Plug



Class II Power Supply



Do not cover










SELV




| Model | | BNV-15-12 | BNV-15-24 |
|--------------|---|--|-----------|
| Output | DC voltage | 12V | 24V |
| | Voltage tolerance | ±5% | |
| | Rated current | 1.25A | 0.625A |
| | Rated power | 15W | |
| Input | Voltage range | 180-264VAC | |
| | Frequency range | 47-63HZ | |
| | Power factor | PF ≥0.65 (50% load), 0.8 (100% load) | |
| | Full load efficiency (Typ.) | 83% | 85% |
| | AC current (Max.) | 0.13A | |
| | Leakage current | 0.7mA | |
| | Inrush current | Cold Start 60A at 230 VAC | |
| Protection | Short circuit | ≤0.6W - Hiccup mode, auto-recovery after short circuit removed | |
| | Over load | 1.4 times rated load. Auto-recovery after overload removed | |
| | Over Voltage | 1.5 times of rated output voltage. Cycle power to recover | |
| | Over Temperature | IC detect = TC 115° | |
| Environment | Working TEMP. | -20~+45°C (refer to derating curve) | |
| | Working humidity | 10-90%RH | |
| | Storage TEMP., humidity | -40~+85°C, 5-95%RH | |
| Safety & EMC | Safety standards | AS/NZS 61347.2.13 | |
| | Withstand voltage | I/P-O/P: 3.75KVAC / 5mA. Max /60s | |
| | Isolation resistance | I/P-O/P:≥10MΩ/500VDC/25°C | |
| | EMC emissions (Note 3.) | EN IEC 61000-3-2, EN55015 | |
| Others | Net. weight | 0.08KG | |
| | Size | 103*35.5*16mm (L*W*H) | |
| Notes | All parameters NOT specially mentioned are measured at 230VAC input at rated load and 25°C of ambient temperature. testing and certification on the final equipment. Recommended loading range from 10% to 100%. Specifications are subject to change without prior notice. Contact your supplier to confirm any critical parameters. | | |

MechanicalSpecification




- Connect LED to LED driver via screw terminals under removable cover. Positive (LED+), Negative (LED-).
- Incorrect wiring could result in damage to the power supply, which is not covered by the warranty.
- Contact ADM with specific input, or output configuration requests.




Connection Diagram



Single Driver Connection Diagram




Multiple Driver Connection Diagram



De-rating Curve





· If being used in higher ambient temperatures, ensure the load on the LED driver is de-rated in accordance with this chart. Failure to do so could lead to a failure, which is not covered by the warranty



Instruction:

- 1) This LED driver should be installed by a qualified electrician.
- 2) Please make sure the LED driver is installed with adequate ventilation around it to allow for heat dissipation.
- 3) Ensure that all wiring is correct before testing in order to avoid damage to the LED driver, or the LEDs.